




# SCRAPPING & DISPOSAL, SPARE PARTS DIAGRAM MODEL AEX20

## 7.2 SPARE PARTS

**TABLE 1**



BOM ID	Description	Part Number
1	Die Ring	APA28M00064
2	Auger	APA28M00102
3	Mixing Arm Bushing	APA28M00106
4	Mixing Arm Knob	ACAEL000089
5	Water Hose Fitting	ACPRA000056
6	Die Wrench	APA28C00071
7	Hopper	APA28A00097
8	Mixing Arm	APA28A00099
9	Lid	APA28C00103
10	Lid Safety	ACYBM000019
11	Touchscreen	APA28X00076
12	Cutting Knife Assembly	APA28A00004

BOM ID	Description	Part Number
13	Mixer Shaft Seal	APA28M00046
14	Bearing	ACACU000008
16	Mixer Spacer	APA28C00044
17	Mixer Driveshaft	APA28M00041
18	Auger Gear	ACAPG000030
19	Motor	ACYAT000203
20	Rear Cover	APA28C00008
21	Main Electric Board	APA28X00075
22	Cooling Fan	ACYAT000001
23	Gearbox	ACARI000166
24	Roller Chain	APA28A00092
25	Mixer Gear	ACAPG000031


BOM ID	Description	Part Number
26	Auger Driveshaft	APA28M00070
27	Auger Spacer	APA28C00040
28	Bearing	ACACU000007
29	Bearing Plate	APA28A00068
31	Thrust Bearing	ACARS000002
33	O-Ring for Auger Seal	ACAOR000049
34	Auger Shaft Seal	APA28M00045
35	Foot Insert	ACAEL000037
36	Foot	ACAEL000083



**SCRAPPING & DISPOSAL,  
SPARE PARTS DIAGRAM**  
MODEL AEX20

**7.2 SPARE PARTS**

**TABLE 1**



BOM ID	Description	Part Number
1	Cutting Knife Cover	ASP30000020
2	Cutter Motor	ACYAT000204
3	Cutter Motor Fixture Plate	APA28C00021
4	Cutting Knife Frame	APA28A00009

BOM ID	Description	Part Number
5	Cutting Knife Shaft	APA28M00089
6	Cutting Knife Blade	APA28C00024
7	Cutting Knife Collar	APA28M00025
8	Cutting Knife Knob	ACAEL000081

BOM ID	Description	Part Number
9	Cutting Knife Cord and Plug	APA25A00020
10	Cutting Knife Outlet	ACYBM000077