



ARCOBALENO™

SPARE PARTS & ELECTRICAL DIAGRAM

MODEL APSS200 PARALLEL

6.1 PARTS, DIAGRAMS & SPARE PARTS

Should the machine be scrapped, you need to arrange for disposal of its parts by taking into consideration their different nature. For the above purpose, it may be advisable to contact companies specialized in this field which, in any case, abide by the law in force in the machine installation country as to disposal of solid industrial wastes.




WARNING: Don't drop the machine in very busy areas as it might endanger persons lives, minors and animals in particular; the owner of the machine shall be held responsible for any claims arising in connection with the above.



ARCOBALENO™


**SPARE PARTS &
ELECTRICAL DIAGRAM**
MODEL APSS200 PARALLEL

APSS200 PARALLEL OVERALL DIMENSIONS DIAGRAM





APSS200 PARALLEL PARTS DIAGRAM





ARCOBALENO™

SPARE PARTS & ELECTRICAL DIAGRAM

MODEL APSS200 PARALLEL

APSS200 PARALLEL PARTS DIAGRAM KEY

Item	Description
1	Lower Safety Device
2	Pizza Chute
3	Upper Safety Device
4	Dough Ball Roller
5	Controls
6	Frame
7	Power Control
8	Support
9	Two Groove Pulley
10	One Groove Pulley
11	Long Belt
12	Back Casing
13	Motor
14	Support Motor
15	Fan Unit
16	Short Belt
17	Lower One Groove Pulley
18	Base
19	Pedal Cable
20	Pedal
21	Lower Chute Distance Piece
22	Base
23	Upper Chute Distance Piece
24	Main Switch
25	Soft Pasta Scraper
26	Block
27	Internal Roller
28	External Roller
29	Outer Pasta Scraper
30	Internal Pasta Scraper
31	Protection Bar
32	External Shaft
33	Spider Counterspider Kit
34	External Gears
35	Bearing 6200
36	Stopper
37	Worm Screw
38	Regulator
39	Bearing 6202
40	Block
41	Internal Gears

42	Internal Shaft
43	Block
44	Internal Roller
45	Internal Shaft
46	Block
47	External Shaft
48	External Roller
A	Lower Block
B	Upper Block