



PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

7.1 PARTS, DIAGRAMS & SPARE PARTS

Should the machine be scrapped, you need to arrange for disposal of its parts by taking into consideration their different nature. For the above purpose, it may be advisable to contact companies specialized in this field which, in any case, abide by the law in force in the machine installation country as to disposal of solid industrial wastes.

WARNING: Don't drop the machine in very busy areas as it might endanger persons lives, minors and animals in particular; the owner of the machine shall be held responsible for any claims arising in connection with the above.




ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 1






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 2






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 3






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 4






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 5






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 6






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 7






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 8





ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 9






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 10






ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 11 - VACUUM





ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 12





ARCOBALENO®
PASTA MACHINES

PARTS & ELECTRICAL DIAGRAMS

MODEL AEX440M

TABLE 13

